

Important Safety Information

English

Thank you for choosing KEF. KEF is dedicated to produce premium audio products with best-in-class sound quality to give you an engrossing and pleasurable listening experience that is true to the original performance.
For your own safety, please read the product manual and important safety information before you use the appliance.
For any other services, please contact your local authorised KEF distributor, whose details can be found at www.kef.com.

Read Instructions - All the safety and operating instructions should be read before operating the appliance.

Retain Instructions - The safety and operating instructions should be retained for future reference.

Heed Warnings - All warnings on the appliance and in the operating instructions should be adhered to.

Follow Instructions - All operating and use instructions should be followed. Only use attachments/accessories specified by the manufacturer.

Installation - Note the weight of the appliance. Never place the appliance on an unstable surface. The appliance may fall and cause serious injury.

Do not place the appliance on high furniture (e.g. shelves, cabinets) without anchoring both furniture and appliance securely.

Water and Moisture - The appliance should not be used in or near water, for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, near a swimming pool, and the like. The appliance shall not be exposed to dripping or splashing. Care should be taken so that objects containing liquids are not placed upon or spilled into the enclosure through openings and that no objects filled with liquids, such as a vase, shall be placed on the appliance.

Heat - The appliance should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.

Do not place any naked flames, such as candles, on the appliance.

Handling - The appliance should be transported with the cart, stand, tripod, bracket, or table specified by manufacturer, or sold with the apparatus. When a cart is used, pay caution when moving the cart/ appliance combination to avoid injury from tip-over.

Operation - Continuous listening to very loud program material via loudspeakers can lead to permanent hearing loss. Prevent damage to your health and avoid continuous listening at high volumes.

Non-use Periods - Unplug the appliance during lightning storms or when unused for long periods of time.

Cleaning - The appliance must be disconnected from the power supply or pairing devices before cleaning. Clean with a dry lint free cloth. Do not use any harsh cleaning agents, spirit based cleaners or solvents.

Damage Requiring Service - The appliance should be serviced by qualified service personnel when:

- a) The power supply cord or the plug has been damaged; or
- b) Objects have fallen: or
- c) Liquid has been spilled into the appliance; or
- d) The appliance has been exposed to rain; or
- e) The appliance does not appear to operate normally or exhibits a marked change in performance; or
- f) The appliance has been dropped or the enclosure is damaged.

Servicing - The user shall not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.